

## **Directions for Balancing & Sanitizing Spa Water**

### **Initial Fill**

- 1.) Add BROMINE or CHLORINE tablets into feeder and put into spa.
- 2.) Add 3/4 CUP of ALKA-RISE and allow to mix thoroughly.
- 3.) Dissolve 1 CUP of CAL-RISE with water, add to spa and allow to mix thoroughly.
- 4.) Add 8 CAPFULLS of PREVENT II and 2 CAPFULLS of SPA CLEAR.
- 5.) Add 1/4 CUP of Shock (LITHIUM or OXY OUT) and allow to mix thoroughly, leaving the cover off for 30 min. to 1 hr. to prevent cover damage.

### **Weekly Maintenance**

- 1.) Spray off your filter with a garden hose.
- 2.) Test the spa water with your home kit and make any pH/Chlorine/Bromine adjustments (if necessary).
- 3.) Add 4 CAPFULLS of PREVENT II and 1 CAPFULL of SPA CLEAR
- 4.) Add 1/4 CUP of Shock (LITHIUM or OXY OUT) and allow to mix thoroughly leaving the cover off for 30 min. to 1 hr. to prevent cover damage.
- 5.) Refill BROMINE or CHLORINE tablets.

### **Maintenance Timeline**

Every 3 months: DRAIN AND RE-FILL SPA

Every 3 months: SOAK FILTER IN CLEANER (CARTRIDGE CLEANER OR FILTER FREE)

Every 3 months: CLEAN & TREAT VINYL COVER (RESTORE VINYL COVER CLEANER)

Every 3 months: CHECK EQUIPMENT FOR LEAKS

Every 12 months: REMOVE BIO-FILM AND CLEAN PLUMBING (SPA PURGE)

Every 12 months: REPLACE CARTRIDGE FILTER