

## **Directions for Balancing Spa Water Using pH Stable**

### **Initial Fill**

- 1.) Add BROMINE or CHLORINE tablets into feeder.
- 2.) Add 3/4 CUP of ALKA RISE and allow to mix thoroughly.
- 3.) Test your pH or bring a water sample to us. pH must be between 7.3 - 7.5
- 4.) Add 750 mL of pH STABLE into spa and wait 1 hr.
- 5.) Add 1 LID of ULTRA SPA and allow to mix thoroughly.
- 6.) Add 1/4 CUP of Shock (LITHIUM or OXY OUT) and allow to mix thoroughly leaving the cover off for 30 min. to 1 hr. to prevent cover damage.

### **Weekly Maintenance**

- 1.) Spray off your filter with a garden hose.
- 2.) Test your spa water and adjust the pH (if necessary), it must be between 7.3 - 7.5
- 3.) Add 50 mL of pH STABLE and wait 30 min.
- 4.) Add 1/2 LID of ULTRA SPA and allow to mix thoroughly.
- 5.) Add 1/4 CUP of Shock (LITHIUM or OXY OUT) and allow to mix thoroughly leaving the cover off for 30 min. to 1 hr. to prevent cover damage.
- 6.) Refill BROMINE or CHLORINE tablets.

### **Maintenance Timeline**

Every 3 months: DRAIN AND RE-FILL SPA

Every 3 months: SOAK FILTER IN CLEANER (CARTRIDGE CLEANER OR FILTER FREE)

Every 3 months: CLEAN & TREAT VINYL COVER (RESTORE VINYL COVER CLEANER)

Every 3 months: CHECK EQUIPMENT FOR LEAKS

Every 12 months: REMOVE BIO-FILM AND CLEAN THE PLUMBING (SPA PURGE)

Every 12 months: REPLACE CARTRIDGE FILTER